

Instructions for Shimming Overlay Door



WARNING

DO NOT ATTEMPT TO INSTALL, REPAIR OR ADJUST the External Lift Cable Mounting System with spring tension applied to the lift cable. Failure to remove all tension could cause SEVERE INJURY OR DEATH if mishandled.

NEVER PLACE HANDS BETWEEN DOOR SECTIONS WHEN LIFTING DOOR.
Severe pinching hand injury could occur.

Should the transition between any two sections show an uneven fit, shims are provided to even up the two surfaces. This is accomplished by removing the two hinge screws from the top or bottom of a hinge and slipping a shim under the hinge leaf before fastening the hinge back in place. Multiple hinge shims are provided for each hinge location along the door section showing the uneven fit.

CAUTION: Install only one hinge shim at a time and fasten down before installing the next hinge shim along a section.

